各服务器route和ip配置:

1.进入netplan目录查找配置文件

```
cd /etc/netplan
```

2.修改网络配置文件

```
sudo vim 01-network-manager-all.yaml
```

3.修改内容

存储了静态路由-终端


```
network:
  version: 2
  renderer: NetworkManager
  ethernets:
      eno2:
          addresses: [10.172.172.2/24]
          dhcp4: no
          dhcp6: no
          #qateway4: 10.172.172.1 这里注释掉的原因是因为这个会加默认路由,网关为这个
          nameservers:
             addresses: [202.112.144.236]
          routes:
              - to: 10.172.172.0/24 # 这个是在子网内
                via: 10.172.172.2
               - to: 10.0.0.0/8 # 这个是不同子网之间
                via: 10.172.172.1
```

不存储静态路由-交换机-网关

```
network:
    version: 2
    renderer: NetworkManager
    ethernets:
        ens1f3:
            addresses: [10.162.162.1/24]
            dhcp4: no
            dhcp6: no
            nameservers:
                 addresses: [202.112.144.236]
```

挂两个终端

```
network:
  version: 2
   renderer: NetworkManager
   ethernets:
       ens42f0:
           addresses: [10.174.174.1/24]
           dhcp4: no
           dhcp6: no
           nameservers:
               addresses: [202.112.144.236]
       ens42f1:
           addresses: [10.180.180.1/24]
           dhcp4: no
           dhcp6: no
           nameservers:
               addresses: [202.112.144.236]
```



4.重启应用设置

```
sudo netplan apply
```

5.检查

```
ifconfig
route -n
```

附录-常用命令

```
#加默认路由
sudo route add default gw 192.168.199.1 dev enxf8e43b9d9975
#删除默认路由
sudo route del default gw 网关
#加路由
add 增加路由 del 删除路由 -net 设置到某个网段的路由 -host 设置到某台主机的路由 gw 出口网关
IP地址 dev 出口网关 物理设备名
```